



INSTRUCTIONS: (1) PURCHASE THIN (.011") ALUMINUM FLASHING. GIBRALTAR BUILDING PRODUCTS #RV710A OR #RV625A FROM HOME DEPOT / LOWES IS IDEAL. (2) CUT OUT THIS PATTERN AND TAPE THE ENDS TOGETHER. (3) TRACE ONTO FLASHING USING A FINE SHARPIE MARKER. (4) CUT THE FLASHING WITH ORDINARY SCISSORS (THIN ALUMINUM FLASHING WILL NOT HURT THEM). (5) DRILL THE TWO RELIEF HOLES THEN MAKE A SLIT BETWEEN USING A RAZOR KNIFE. (6) PUNCH THE VENT HOLES WITH A SINGLE HOLE PAPER PUNCH. (7) SMOOTH EDGES WITH FINE SANDPAPER IF DESIRED. THAT'S IT! NOW GO OUTSIDE AND HAVE FUN!

REDHOT DIY WINDSCREEN PATTERN